



## COASTAL AWNING WINDOWS

*500 Series High-Performance Awning, 200 Series Advantage Awning and Scissor Awning*

### CLEANING

**Vinyl Frames and Sashes**—simply use a mild, nonabrasive soap and water solution to clean your vinyl frames and sashes. NEVER use chlorine bleach, liquid grease remover, nail polish remover (acetone) and other harsh or abrasive cleansers, detergents and solvents. **Glass**—use a mixture of mild dish soap and water, then rinse completely with clear water and wipe dry with a soft cloth.

**Screen Removal**—awning screens are mounted on the interior of the window. *500 Series High Performance Awning*—the screen is held in place by spring tabs on the bottom. To remove the screen, grasp the pull-tabs located at the top and pull down and inward. *200 Series Advantage Awning and Scissor Awning*—the screen is held in place by springs on the top. To remove the screen, grasp the pull-tabs located at the bottom and pull up and inward. **Screen Cleaning**—to clean your screens of dust and light debris once they are removed, gently scrub with mild soap and a soft brush. Screens should be rinsed to remove dirt and soap residue. Be sure that screens are dry before they are re-installed.

### OPERATION

Awning windows are hinged at the top and crank open. The Coastal Advantage Awning window has the operator mounted on the side and is designed to open approximately 90 degrees or less. Coastal Scissor and High Performance Awning windows are designed to open approximately 45 degrees or less. All three styles feature dual cam locks.\* Both locks must be released before opening or you will risk damaging the operating mechanism.

**To open the window**, lift the lock handles to release the locks (you should hear a gentle click), then lift the handle operator and rotate to crank the window open. **To close the window**, reverse the steps. Be sure to lock both cam locks whenever the window is closed.\*

\*Smaller windows may have one lock.

### MAINTENANCE

It is important that the tracks and hinges are cleaned of dirt and debris on a regular basis. To keep these parts clean, brush them with a soft dry brush. Use a silicone based lube to lubricate the pivot point in the arm of the roto operator every other month. Lubricate monthly in oceanfront locations.

## COASTAL CASEMENT WINDOWS

*500 Series High-Performance Casement, 200 Series Casement*

### CLEANING

**Vinyl Frames and Sashes**—simply use a mild, nonabrasive soap and water solution to clean your vinyl frames and sashes. NEVER use chlorine bleach, liquid grease remover, nail polish remover (acetone) and other harsh or abrasive cleansers, detergents and solvents. **Glass**—use a mixture of mild dish soap and water, then rinse completely with clear water and wipe dry with a soft cloth. **Screen Removal**—casement screens are mounted on the interior of the window. The screen is held in place by springs on the bottom. To remove the screen, grasp the pull-tabs located at the top and pull down and inward. **Screen Cleaning**—to clean your screens of dust and light debris once they are removed, gently scrub with mild soap and a soft brush. Screens should be rinsed to remove dirt and soap residue. Be sure that screens are dry before they are re-installed.

### OPERATION

Casement windows are hinged on the side and crank open. Coastal Casement windows also feature dual cam locks. Both locks must be released before opening or you will risk damaging the operating mechanism.

**To open the window**, starting with the bottom lock, lift the lock handles to release the locks (you should hear a gentle click), then lift the handle operator and rotate to crank the window open. **To close the window**, reverse the steps, closing the window and locking the bottom lock first, then the top lock. Be sure to lock both cam locks whenever the window is closed.

### MAINTENANCE

It is important that the tracks and hinges are cleaned of dirt and debris on a regular basis. To keep these parts clean, brush them with a soft dry brush. Use a silicone based lube to lubricate the pivot point in the arm of the roto operator every other month. Lubricate monthly in oceanfront locations.